




Changing Set Temperature



1. Press for 5 seconds



Push three times get to -r- and push



Use to go to r03 and press

To change from heat to cool push the for 5 second. This turns off the heat mode. Then push for 5 seconds and you will see the In the display screen. To change back reverse the process.



Heating set point is -r03-. Cooling set point is -r01-

Use the or arrows to get to the desired setting and then push Push 3 times until you get back to the display temperature or leave for one minute and the display will go back to the display temperature